

Protocol 22 · NPWT dressing change and troubleshooting: for nurses

Scope: **General** · Wiki page: **protocols/dressing-change-troubleshooting** · Source: wondsorg NPWT clinical wiki, content as at 2026-10-04

General. The bedside page. Its skeleton is the only formal analysis of how NPWT care fails: thirteen failure modes across prescription, application, monitoring and removal, with bleeding ranked first.

Before you start

- Read the prescription: indication, pressure, mode, interface, interval, endpoint, review date. A missing item is a stop; an absent or inadequate prescription is the first failure mode.
- Check the chart: anticoagulation; pacemaker or ICD (pump at least 15 cm from the generator, away from the chest); fall risk; level of consciousness; adhesive allergy.
- Analgesia given and working before removal. Foam hurts more than gauze at removal (6.5 versus 4.15 on a 10-point scale); in a blinded trial 65 percent nitrous oxide cut pain at removal from a median 6.3 to 3. Pain at changes is the commonest reason patients ask to stop.
- Lay out the new dressing before opening the old one; have a saline syringe ready to soak a stuck foam.

Removal

- Pump off, disconnect. Look at the canister and tubing for blood first.
- Lift the drape gently, supporting the skin; adhesive remover on fragile skin. Soak an adherent foam with saline and wait; never pull a stuck foam.
- Count every piece out and reconcile against the count in; record the number. A piece that does not come out is a retained foreign body with no radio-opaque marker; it presents weeks to years later as a wound that will not heal.
- Inspect: bleeding; the wound edge (dusky or black over a poorly perfused limb); surrounding skin (blistering, maceration); exposed structures; odour; slough. Measure length, width and depth; photograph with the date; record exudate.

Application

- Debridement is the surgeon's: do not re-dress over dead tissue or undrained infection; call. If infection is suspected, the specimen is a tissue biopsy at debridement, not a swab or the foam; for a chronic wound add fungal culture and histology.
- Protect any exposed vessel, tendon, bone or hardware with the prescribed non-adherent layer.
- Cut foam to the wound, not larger; fewest pieces; count in and record. Never cut foam over the wound.
- Skin protectant on intact skin; hydrocolloid strips around a difficult margin and drape onto them; no iodine cleaning of the skin before draping (the residue stops the film sticking). Seal 2 to 3 cm beyond the margin; bridge tubing away from bony prominences and, under compression, out above the bandage.
- Connect, set the prescribed pressure and mode, watch the dressing draw down and stay down. Record pressure, mode, pieces in, time, and who did it.

The seal, the commonest problem

- On a device: a leak alarm that does not clear in minutes is a change, not a wait. Find the leak by feel and by listening; patch with drape strips; skin folds, the natal cleft, pins and tubing exits are the usual sites.
- On wall suction: clamp the tube and watch the manometer; no excursion means no leak, and the excursion measures it. A working gauze dressing visibly shrinks. Read the manometer every shift: wall suction delivers about 7 percent above the dial.
- A seal that cannot be restored within two hours leaves the wound under an unventilated wet dressing: change it. A Redon bottle or bulb drain is not NPWT; its vacuum decays to nothing within minutes.

Bleeding

Fresh blood in the tubing or canister, a sudden change in output, an unexplained haemoglobin fall, or a lost seal over a vascular repair: pump off, direct pressure, call the surgeon. Do not wait for the canister to fill; one tibial-artery erosion cost six units with only 600 mL ever visible in the canister. Bleeding over a repair is late (median day 18) and usually on a background of infection: a wound that becomes infected under NPWT over a graft is a bleeding risk, not only an infection.

Other problems, and what each means

Pain rising between changes	Ischaemia, infection, foam on a nerve, pressure too high: inspect now, do not wait for the scheduled change.
Skin blistering at the edge	Drape tension, shear, adhesive: reapply without tension, skin protectant, document (the best-corroborated harm, RR 3.55).

Maceration	Leak, exudate not clearing, instillation leaking: restore the seal, check the canister, reduce dwell or volume.
Foul smell, fever, spreading redness	Infection under the dressing: change and inspect the same day, culture, call.
Wound worse with negative cultures	Consider pyoderma gangrenosum: stop NPWT and call; pathergy makes it worse.
Paced heart rate has changed	Pump magnet over the generator: move the pump away from the chest now; tell the doctor.
Canister filling fast	Bleeding or a lymph leak: look for blood, measure, call if blood.
Alarm at night, patient anxious	Seal, canister, battery: fix the cause, reassure (anxiety is expected early and settles), record.
Power failure of two hours or more	An FDA-listed failure mode: change the dressing if suction cannot be restored.
Instillation not filling or clearing	Line clamped, wrong foam, leak: run a test cycle at the bedside before leaving the patient.

Intervals, and what to write

Foam every 48 to 72 hours (24 to 48 if infected); gauze on wall suction daily; a first change at a mean of 2.9 days was safe even in contaminated wounds; a graft bolster undisturbed 4 to 5 days; instillation at 48 to 72 hours with the planned re-look. Every time: pressure, mode, pieces in and out, seal check, canister volume and character, pain score, measurements and photograph, wound edge, surrounding skin, coping, next change date. A wound that has not progressed for four weeks is a stop, not a reason to extend.

References

- Lelong AS, Martelli N, Bonan B, Prognon P, Pineau J. Use of a risk assessment method to improve the safety of negative pressure wound therapy. *Int Wound J* 2014;11(3):253-258. doi:10.1111/j.1742-481X.2012.01081.x [wiki: lelong-2014-npwt-risk-assessment-fmeca]
- Anagnostakos K, Thiery A, Sahan I. Retained Negative Pressure Wound Therapy Foams as a Cause of Infection Persistence. *Advances in Wound Care (New Rochelle)* 2021;10(12):699-710. doi:10.1089/wound.2019.1088 [wiki: anagnostakos-2021-retained-foam-review]
- Fraccalvieri M, Ruka E, Bocchiotti MA, Zingarelli E, Bruschi S. Patient's pain feedback using negative pressure wound therapy with foam and gauze. *Int Wound J* 2011;8(5):492-9. doi:10.1111/j.1742-481X.2011.00821.x [wiki: fraccalvieri-2011-pain-foam-vs-gauze]
- Xing Y, Lv R, Xie C, Cao W, Dou J, Jiang X, et al. Premixed nitrous oxide/oxygen analgesia for removal of vacuum assisted closure dressing: a randomized, double-blinded placebo-controlled trial. *Scientific Reports* 2026;16:18409 (article number). doi:10.1038/s41598-026-46571-1 [wiki: xing-2026-nitrous-oxide-vac-dressing-pain-rct]
- Amouzou KS, Youssef AEL, Kouevi-Koko TE. A simple way to monitor the seal in the domestic negative-pressure wound therapy dressing. *Wound Healing Southern Africa* 2019. [wiki: kouevikoko-2019-seal-monitor]
- Isaac AMA, Salim ME, Ahmed IAM. An affordable custom-built negative pressure wound therapy. *Ann Afr Surg* 2017;14(1):55-56. doi:10.4314/aas.v14i1.12 [wiki: isaac-2017-affordable-custom-built-npwt]
- Eksteen EC, Volkwyn LE, Wells H. Negative-pressure wound therapy for hospitalised patients: a paradigm shift. *Wound Healing Southern Africa* 2024;17(2):32-37. doi:10.36303/WHSA.1116 [wiki: eksteen-2024-paradigm-shift]
- Schalamon J, Petnehazy T, Ainoedhofer H, Castellani C, Till H, Singer G. Experimental comparison of abdominal drainage systems. *The American Journal of Surgery* 2017;213(6):1038-1041. doi:10.1016/j.amjsurg.2016.09.043 [wiki: schalamon-2017-drainage-system-vacuum-decay]
- White Richard A, Miki Roberto A, Kazmier Peter, Anglen Jeffrey O. Vacuum-assisted closure complicated by erosion and hemorrhage of the anterior tibial artery. *Journal of Orthopaedic Trauma* 2005;19(1):56-59. doi:10.1097/00005131-200501000-00011 [wiki: white-2005-tibial-artery-erosion-npwt]
- Sivash II, Koval BM. Negative pressure wound therapy for combat-related extremity vascular injuries: clinical experience from the war in Ukraine. *Scandinavian Journal of Trauma, Resuscitation and Emergency Medicine* 2025;33(1):188. doi:10.1186/s13049-025-01502-3 [wiki: sivash-2025-combat-vascular-npwt-cohort]
- Norman G, Shi C, Goh EL, Murphy EMA, Reid A, Chiverton L, et al. Negative pressure wound therapy for surgical wounds healing by primary closure. *Cochrane Database Syst Rev* 2022;4(4). doi:10.1002/14651858.CD009261.pub7 [wiki: norman-2022-cochrane-npwt-primary-closure]
- Lehnert R, Schneider S, Walker B, Schrednitzki D. Postoperative Pyoderma Gangrenosum Mimicking Early Periprosthetic Joint Infection After Total Hip Arthroplasty in a Patient With Hairy Cell Leukemia: A Diagnostic Challenge. *Cureus* 2026;18(6):e111606. doi:10.7759/cureus.111606 [wiki: lehnert-2026-pyoderma-gangrenosum-npwt-pathergy]
- Caldecott R, Laffey J. Underrecognized Interaction Between PICO Dressings and Pacemakers: A Case From the ICU. *Case Rep Anesthesiol* 2026;2026(—):2189554. doi:10.1155/cria/2189554 [wiki: caldecott-2026-pico-pacemaker-magnet-interaction]
- Keskin M, Karabekmez FE, Yilmaz E, Tosun Z, Savaci N. Vacuum assisted closure of wounds and anxiety. *Scand J Plast Reconstr Surg Hand Surg* 2008;42(4):202-5. doi:10.1080/02844310802091586 [wiki: keskin-2008-vac-anxiety-rct]
- Shweiki E, Gallagher KE. Assessing a Safe Interval for Subsequent Negative Pressure Wound Therapy Change After Initial Placement in Acute, Contaminated Wounds. *WOUNDS* 2013;25(9):263-271. [wiki: shweiki-2013-dressing-interval]
- US Food and Drug Administration. FDA Safety Communication: UPDATE on Serious Complications Associated with Negative Pressure Wound Therapy Systems. US Food and Drug Administration, Center for Devices and Radiological Health 2011. [wiki: fda-2011-npwt-safety-communication]